



The Keys | Installation Instructions

Non-Woven Wallcoverings

1. **PREPARATION:** Remove old wall-coverings. Ensure all holes and cracks are filled and that walls are smooth. Walls must be treated with primer. Verify that run number on all rolls is the same.
2. Measure from a corner of the room or 1" less than the width of the product and draw a vertical line using either a level or a plumb line.
3. Measure height of the wall and cut the strip allowing an extra 2" at both the top and bottom. Before cutting the second strip examine the pattern match in order to avoid unnecessary waste.
4. Following paste manufacturer's directions, apply paste directly to wall using a paint roller on the main wall and a brush in corners, near ceiling & baseboards and around windows & doors. Apply enough paste to cover at least 2" more than the width of the product. (You may want to apply enough paste to handle two strips of product at a time).
5. Apply dry product strips directly to pasted wall. Note: Work from top of strip down. Smooth paper to wall, carefully removing bubbles without creasing the product. Note: Best to work bubbles out vertically being careful not to squeeze paste out onto the product.
6. Trim excess paper at top and bottom using a straight edge and razor knife.
7. Apply remaining strips following steps 4 through 6, ensuring pattern match is correct before smoothing.
8. Remove excess paste from all surfaces using sponge and clean tepid water.
9. When it is time to redecorate you will really understand the value of product. Simply peel an edge of the product and pull the strips from the wall one by one. In moments you will be ready to redecorate using another great product design.

For additional information or technical support contact Winfield Customer Service at 800-468-6800.

Marketed Nationally by Kravet Inc.

400 High Grove Blvd., Glendale Heights, IL. 60139
Tel: 800-486-6800/Customer Service Fax: 800-430-6807