

# INSTALLATION INSTRUCTIONS

## STILLEWALL ACOUSTICAL WALLCOVERING

### INSPECTION

Examine material prior to installation. Check to see that all rolls match one to the other. Before cutting, be sure the pattern and color are satisfactory. For best results, it is recommended that a qualified textile wallcovering installer be employed.

### SURFACE PREPARATION

For best results, clean and properly prepare all wall surfaces. Old wallcovering and paste residue should be removed. Walls must be clean, dry, and smooth. Prepare surface with a premixed universal wallcovering primer. The primer should be tinted to the same color as the background color of your wallcovering to help hide seams. **All wallcovering must be hung under permanent lighting.**

**NOTE:** Install (3) strips, stop and inspect the installation. If the installation is not satisfactory by the customer, stop hanging and call your retailer for assistance. In the event of any issue, please quote the item and run number that is on the roll label.

### ADHESIVE

- Heavy Duty, Clear, Non-Staining Adhesive. **DO NOT DILUTE.**
- **AVOID** adhesive contacting the face of the wallcovering. Staining and discoloration can occur and **CANNOT** be repaired.

### INSTALLATION

1. Carefully inspect all rolls (rolls are shipped separately in heavy duty poly bags) and we will not be responsible for damage after goods are cut.
2. Material is designed to be dry hung (do not use a pasting machine).
3. Apply premixed, heavy-duty vinyl wallcovering adhesive directly to the wall and allow it to dry overnight.
4. **IMPORTANT:** Adhesive is ready mixed and should not be diluted. **DO NOT APPLY PASTE TO THE BACK OF THE WALLCOVERING.**
5. Once the first coat of wallcovering adhesive is completely dry, apply a second coat of undiluted adhesive to the wall and allow the adhesive to dry until it has a slight tack-ability to the touch.
6. Wallcovering should be hung straight up without alternating strips (All seams should be vertical, nap going the same way, and at least six inches away from the inside or outside of corners). For best results, apply full widths of material wherever possible. Headers and doors may cause shading.
7. Begin hanging by cutting the first wallcovering strip to the desired length, adding 2 inches for overlap onto ceiling and 2 inches for overlap onto base. Material is not factory

trimmed – it is necessary for installer to cut a straight edge. All edges must be buttjoined.

8. Continue to install a second and third strip following the same process as with the first strip. Inspect the three strips for color, uniformity, and proper application. Continue installation, stopping to inspect for product correctness and proper application every three strips. If a problem is detected after any three strips are applied, STOP WORK IMMEDIATELY and call Customer Service. (Shading is normal due to the lustrous needle-punch pile and should not be considered a defect).

**For additional information or technical support contact  
Winfield Customer Care at 224-366-4980**

**Marketed Nationally by Kravet LLC**